


ATSCO

DEMOLITION TOOL MODELS RB08, RB11



CAUTION
DO NOT OPERATE A HAMMER
WITHOUT EYE PROTECTION!
Use adequate EAR PROTECTION

For Parts Call Tools Renewed (800) 247-3639 Fax (860) 665-9821

MODELS RB08, RB11 DEMOLITION TOOL

Item #	Part #	Description
1	69A-RB08	HANDLE ASSEMBLY
2	31-RB08	LEVER
3	32-RB08	PIN
4	63-CPR	BUSHING
5	27A-RB08	BUSHING
6	27-RB08	BUSHING ASSEMBLY
7	93-21	O RING
8	28-RB08	PIN
9	25-RB08	THROTTLE VALVE
10	26-412	THROTTLE SPRING
11	30-RB08	CAP
11A	5000-106	RET RING
12	93-21	O RING
13	90A-RB08	CYLINDER (RB08)
	90A-RB11	CYLINDER (RB11)
14	46-RB08	RING
15	36-TR	DEFLECTOR
16	40B-11X	SLEEVE (UPPER)
17	39A-11X	SLEEVE (LOWER)
18	37A-11X	BUMPER
19	12-RB08	RETAINER
20	17-CPR	RETAINER SPRING
21	2-CPR4X	PISTON (RB08)
	2-CPR5X	PISTON (RB11)
	54A-RB08	VALVE BOX COMPLETE
22	28-CPBBS	PIN
23	52-RB08	VALVE CHEST (FRONT)
24	54-83X	VALVE
25	53-RB08	VALVE CHEST (REAR)
26	47-CPRX	SPRING

For Parts Call Tools Renewed (800) 247-3639 Fax (860) 665-9821