


**Parts for Thor Model 38 Rockdrill (45LB)**



Index	Part No.	Description	Index	Part No.	Description	Index	Part No.	Description
1	802970	Fronthead				43	43112	Nut
2	43317	7/8" Hex X 3-1/4"	24	43907	7/8 & 1" Hex X 4-1/4"	44	43169	Swivel Nut
	43320	1" Hex X 4-1/4"		43906	7/8" Hex X 3-1/4"			
	43342	7/8" Hex X 4-1/4"			*Uses 7/16" Bolt Holes			
3	43313	Chuck Driver	25	43562	Plunger (2)	47	43168	Swivel
4	43314	Bearing	26	43377	Bumper (2)	48	45259	O-Ring
5	43176	Valve	27	43560	Housing (2)	49		Swivel Assy.
6	43175	Oil Plug	28	43559	Bolt (4) 7/16"	50	43158	Throttle Valve
7	43312	Cylinder	29	43309	Rifle Bar	51	43322	Side Bolt (2)
8	43094	Felt	30	78883	Spring (3)	52	43155	Plug
9	805412	Plug	31	43204	Plunger (3)	53	43156	Gasket
10		Cylinder Assy.	32	43120	Pawl (3)	54	43144	Packing
11	43311	Piston	33	805436	Pin	55	43164	Air Tube-Dry
12	43306	Rifle Nut	34	44010	Ratchet Ring	56	43293	Backhead-Dry
13	43552	Front Valve	35	43296	Plate	57	43102	Nut
14	43621	Valve	36	68073	Plug	58	43003	Washer
15	43551	Rear Valve	37	43162	Spring	59	43159	Handle
16	43299	Guide	38	43161	Plunger	60	43160	Bolt
17	43181	Pin, Exhaust	39	43127	Grip (2)	67	43323	Side Bolt Nut
18	43180	Washer	40	43005	Washer (2)			
19	43179	Spring	41	43128	Bolt			
22	43558	Nut (4)	42	2602-APT	Plug			
23	43003	Washer (4)						